

MAINTENANCEADVICE

EN

TOP
CORE

TopCore® is a low-maintenance material for the kitchen and bathroom. To keep the kitchen countertop beautiful, proper use and regular cleaning is necessary. The tips below will help you enjoy your kitchen countertop for years to come.

1 DAILY MAINTENANCE

Wipe your kitchen countertop daily with a dishcloth and detergent. Always rinse well with lukewarm water and dry your kitchen countertop with a clean, dry dishcloth or kitchen paper. This will absorb remaining dirt and any soap and water residue.

Periodic maintenance

To maintain your kitchen countertop, you can also use Top Cleaner, a special laminate cleaner that easily removes dirt from the laminate and leaves a lovely fresh scent. This product is available in the online shop. Do always rinse well with lukewarm water and dry your kitchen countertop with a clean, dishcloth or kitchen paper.

2 REMOVING SPECIFIC STAINS

Grease, coffee/tea or red wine

(shiny or brown spots)

Let the Top Cleaner or a detergent soak for a while until the dirt begins to react. Then treat with a melamine sponge. Moisten it slightly and then squeeze it for enough friction. Always rinse well with lukewarm water and dry your kitchen countertop with a clean, dry dishcloth or kitchen paper.

Hard water stains

(dull white or brown spots)

Let the cleaning vinegar soak in for a while. Then treat with a melamine sponge. Moisten it slightly and then squeeze it for enough friction. Always rinse well with lukewarm water and dry your kitchen worktop with a clean, dry towel or kitchen paper. Be careful here that cleaning vinegar cannot come in contact with marble or limestone.

Ink, paint or nicotine

Remove drawn-in stains from ink, paint, nicotine or felt pen with turpentine. Always rinse well with lukewarm water and dry your kitchen worktop with a clean, dry dishcloth or kitchen paper.

3 REMOVE STUBBORN STAINS

Use a melamine sponge and detergent. Always rinse well with lukewarm water and dry your kitchen worktop with a clean, dry dishcloth or kitchen paper. Have the stains or circles diminished but not yet completely gone? Then repeat this process. This treatment is not for the daily maintenance of your kitchen countertop!

Note

- > Never use hard abrasives such as steel wool, sandpaper or diamond. They can permanently damage the kitchen worktop surface!
- > Due to the deeper structure, dirt remains in the pores. This requires more intensive cleaning than with smooth surfaces.



View the
maintenance
video



www.dekkerzevenhuizen.nl/Kennisbank/onderhoudsadvies-topcore



Top Cleaner

Top Cleaner (Art. No. 290126) is a laminate cleaner for daily maintenance. Easily removes dirt from the laminate. You can order this cleaner online: www.dekkerzevenhuizen.nl/shop

More information!

Would you like more information and cleaning tips or read about special offers from professional cleaners? Then visit: www.dekkerzevenhuizen.com/maintenance



Never let liquids dry out. Do not leave fats or foods on the kitchen countertop unnecessarily long.



Always use a trivet near hot objects. Special insulation material is available against heat from certain household appliances.



Never cut directly on the kitchen countertop; always use a cutting board.



Never use aggressive cleaners such as paint strippers, brush, metal or oven cleaners, chlorine, sink de-stoppers or other chemicals!



Textured kitchen countertops leave more dirt behind. Rinsing well with clean water and rubbing dry ensures that no dirt remains in the textured surface.

TopCore® kitchen countertops are available through Dekker Zevenhuizen BV, Postbus 11, 2760 AA Zevenhuizen For warranty conditions, visit www.dekkerzevenhuizen.nl/warranty

DEKKER